

SONY

TRINITRON® COLOR TV BASIC SCHEMATIC DIAGRAM

KV-2184P/RM-687C

Chassis No. SCC-D15C

NOTE

THIS SCHEMATIC DIAGRAM IS FOR USE BY YOUR SERVICE
TECHNICIAN.

KEEP THIS DIAGRAM HANDY FOR FUTURE REFERENCE.

Sony Corporation


© 1989


3-751-353-01

Printed in Japan



Note: All mounting diagrams are viewed from conductor side.

A [TUNER Y/C JUNGLE,
SYSTEM CONTROL
H.V. OUT, POWER SUPPLY.


[illegible]





C BOARD



S BOARD




CAUTION
When replacing HVR, be sure to check the hold down check point voltage value. Refer to the safety adjustment item.




SEMICONDUCTORS

BX-1398




CXA12135




NJM78M09A




PCA84C640P/016




L78LR050-MA



RC78M09FA




ST24C02CP
#PC4558C




STR50115B



TDA2007



#PC1448H




DTA144ES
DTC114ES
DTC144ES




2SA1175-HFE
2SC2785-HFE




2SC2611
2SC2688-LK
2SC3271-N




2S01649-CA




2S01761-E




2SK669




ERC60-15S
RU-3AM
RSM
ZHT33-02TA




ES1F
GP0800PKG23
GPR10G
RGP15G
R05.6EBZ7S
R024EBZ7
U05G




KBU4JL-6088




MC931




R05.1ES-B2
R0602ES-B2
R013ES-B1
ISS119




SEL1222R-C, 0




CXA1214P




LA7016



NJM78L09A





A (TUNER Y/C JUNGLE, SYSTEM CONTROL, H.V. OUT, POWER SUPPLY)

CAUTION
When replacing IC601, be sure to check the test point voltage value pin ④ of IC601. Refer to the safety adjustment item.

