



ФУНКЦИЯ		ФУНКЦИЯ		ФУНКЦИЯ	
1	8	11	5	21	VOL+
2	9	12	6	22	VOL-
3	Q.VIEW	13	7	23	ENTER →
4	RECALL	14	POWER	24	ENTER ←
5	- / -	15	MUTE	25	ENTER ↑
6	0	16	TV/AV	26	ENTER ↓
7	1	17	PICTURE	27	SET-UP
8	2	18	SLEEP	28	ENTER
9	3	19	CH+	29	SMC
10	4	20	CH-	30	PSM

Пульт дистанционного управления