



(RM-C684-H)




KEY No.	FUNCTION	KEY No.	FUNCTION	KEY No.	FUNCTION
1	DISPLAY	17	4	31	--
2	VSM	18	5	42	SOUND SYSTEM
4	VIDEO2	19	6	44	● REC
5	S-□	20	7	45	■ STOP
7	POWER	21	8	47	▶▶ FF
8	CHANNEL V	22	9	48	◀◀ REW
9	CHANNEL ^	23	THEATRE SOUND	49	VTR POWER
10	MUTE	24	+(FUNCTION)	50	▶ PLAY
11	VOLUME+	25	-(FUNCTION)	51	PAUSE
12	VOLUME-	26	MENU	52	TV
13	0	27	▼ (FUNCTION)	53	· VIDEO1
14	1	28	▲ (FUNCTION)	54	VTR CHANNEL-
15	2	29	EE	55	VTR CHANNEL+
16	3	30	COLOUR SYSTEM		

REFER TO THE FOLLOWING PWB PATTERN: MAIN PWB 2-23 page, CONTROL PWB 2-22 page, LED PWB 2-22 page.




AIN PWB, CRT SOCKET PWB CIRCUIT DIAGRAMS

REFER TO THE




REFER TO THE FOLLOWING PWB PATTERN: 2-23 page, CRT SOCKET PWB 2-25 page.




TERMINAL PWB CIRCUIT DIAGRAMS


REFER TO THE FOLLOWING PWB PATTERN: AV TERMINAL PWB 2-27 page.



IC203		L10V - 12V				
	A	B	Qo	Q1	Q2	Q3
TV	L	L	H	L	L	L
V1	L	L	L	H	L	L
V2	L	H	L	L	H	L
S	H	H	L	L	L	H


J.V.C





AUDIO PWB, MUTE PWB CIRCUIT DIAGRAMS

REFER TO THE FOLLOWING PWB PATTERN: AUDIO PWB 2-28 page, MUTE PWB 2-28 page.



AUDIO PWB ASS'Y SKY-6007A-H2

