



5





SUB POWER PWB ASS'Y
SKX-9242A



PWB, MIC JACK PWB CIRCUIT DIAGRAMS


REFER TO THE FOLLOWING PWB PATTERN : AUDIO PWB 2-38 page, MIC JACK PWB 2-33 page.








NOTES
X : OPEN

REFER TO THE FOLLOWING PWB PATTERN : AV TERMINAL PWB 2-30 page.











NOTES
X: OPEN

MAIN PWB ASS' Y
STEREO
IE
OFF
TIMER
GND
EMOCON
5V
IE OUT
12V
GND

ICU
IN P
CO15
100/15
CONTROL
PWB ASS'
SKX-8005



(RM-C961)

KEY. NO	FUNCTION		KEY. NO	FUNCTION	
	TV SIDE	VCR SIDE		TV SIDE	VCR SIDE
1		REM	21		SOUND SYSTEM
2	VIDEO1	STOP	22		COLOUR SYSTEM
3	NOTCH	FF	23	0	0
4	POWER	POWER	24	--	TV/TXT/MIX
5	TV	REC	25		CANCEL
6	VNR	PLAY	26	FUNCTION BACK	TIME PAGE
7	VIDEO2	PAUSE	27		REVEAL
8	S-TH 	EJECT	28	VSM	MODE
9	MENU	CHANNEL A	29	FUNCTION-	STORE
10	1	1	30		RESET
11	2	2	31	FUNCTION+	SIZE
12	3	3	32	HYPER SURROUND	HOLD
13	DISPLAY CB	CHANNEL V	33		RED
14	4	4	34	FUNCTION FORWARD	GREEN
15	5	5	35		YELLOW
16	6	6	36	MUTE	CYAN(BLUE)
17		EE	37	CHANNEL PAGE V	CHANNEL PAGE V
18	7	7	38	CHANNEL PAGE A	CHANNEL PAGE A
19	8	8	39	VOLUME-	VOLUME-
20	9	9	40	VOLUME+	VOLUME+